

修理受付機種一覧

更新日：2019年7月

- 「修理受付機種一覧」に記載の機種でも、故障内容によりましては、修理が不可能な場合もございますので、ご了承くださいますようお願い申し上げます。
- 代替部品での修理になる場合もございますので、ご了承ください。
- すでに消されている機種は、既に部品の供給が終了しておりますので修理をお引き受けできません。
- 弊社にて輸入取り扱いの無い機種につきましては、補修部品等の供給が得られないため、修理をお引き受けできません。

スピーカーシステム

- 1000ARRAY
- 4302
- 4304H
- 4305H
- 4306
- 4307
- 4310H
- 4312D
- 4312E
- 4312G
- 4312M
- 4312MII
- 4312SE
- 4318
- 4319
- 4338
- 4344
- 4344MKⅡ
- 4348
- 4365
- 4367WX

- 4428
- 4429
- 800ARRAY
- 880ARRAY
- A550
- A640
- ARENA 180
- ARENA 120
- ARENA 125C
- C-6IC
- C-6IW
- C-8IC
- C-8IW
- CONTROL 1XTREME
- CONTROL NOW
- CONTROL ONE
- CONTROL 1
- CONTROL 1X
- CONTROL X
- CONTROL X WIRELESS
- DD65000
- DD66000
- DD67000
- ES150PCH
- HB5000
- HC5000
- HTI6
- HTI6C
- HTI8
- HTI88
- K2 S5500
- K2 S5800
- K2 S7500
- K2 S9500

- K2 S9800
- K2 S9800SE
- K2S9900
- L226W
- L228C
- L8400P
- L8400PCH
- LS326C
- LS326W
- LS328C
- LS60
- LS80
- L100 Classic
- LSCENTERE
- M9500
- S1000
- S1500C
- S1800C
- S2000
- S2400
- S2500
- S3500
- S3800
- S3900
- S400
- S4000
- S4600
- S4700
- S4800
- SK2 1000
- STAGE A120
- STAGE A125C
- STAGE A130
- STAGE A180

- STAGE A190
- STAGE SUB A100P
- STUDIO 2 6IC
- STUDIO 2 6IW
- STUDIO 2 6ICDT
- STUDIO 2 8IC
- STUDIO 2 8IW
- STUDIO 210
- STUDIO 220
- STUDIO 225C
- STUDIO 230
- STUDIO 270
- STUDIO 280
- STUDIO 290
- STUDIO 520CCH
- STUDIO 530CH
- STUDIO 570CH
- STUDIO 580CH
- STUDIO 590CH
- STUDIO 620
- STUDIO 625C
- STUDIO 630
- STUDIO 660P
- STUDIO 680
- STUDIO 698
- SUB 100P
- SUB-560PCH
- SV400C
- SV500
- SV50S
- SV800
- TS60
- TS6000
- TS8000

- ~~TZ-1~~
- ~~TZ-1C~~
- ~~TZ-2~~
- ~~TZ-2C~~
- ~~UT-025~~
- ~~UT-405~~

アクティブスピーカー

- Authentics L8
- Authentics L16
- BOOMBOX
- ~~CAS-33~~
- CHARGE
- CHARGE2
- CHARGE2 +
- CHARGE3
- CLIP
- CLIP +
- CLIP2
- CLIP3
- FLIP
- FLIP2
- FLIP3
- FLIP4
- GO
- GO2
- HORIZON
- JEMBE
- JEMBE WIRELESS
- JR POP
- LINK10
- LINK20
- LINK300

- LINK500
- MICRO WIRELESS
- ~~ON STATION MICRO~~
- ~~ON STATION3~~
- ~~ON STATION3P~~
- ~~ON STATION4~~
- ~~ON STATION™ MICRO II~~
- ~~ON STATION™ MICRO II WM~~
- ~~ON STATION™ MICRO III~~
- ~~ONBEAT MICRO~~
- ~~ONBEAT MINI~~
- ONBEAT RUMBLE
- ~~ONBEAT VENUE-LT~~
- PartyBox 300
- PEBBLES
- PLAYLIST
- PULSE
- PULSE2
- PULSE3
- ~~SPARK~~
- SOUNDGEAR
- SOUNDGEAR BTA
- TUNER FM
- ~~VOYAGER~~
- Xtreme
- Xtreme 2

ヘッドホン/イヤホン

- BASSLINE
- DUET BT
- DUET MINI BT
- ~~E15~~
- E25BT

- E35
- E45BT
- E55BT
- E65BTNC
- ENDURANCE DIVE
- ENDURANCE JUMP
- ENDURANCE PEAK
- ENDURANCE RUN
- EVEREST 100
- EVEREST 110
- EVEREST 110GA
- EVEREST 300
- EVEREST 310
- EVEREST 310GA
- EVEREST 700
- EVEREST 710
- EVEREST 710GA
- EVEREST ELITE 100
- EVEREST ELITE 300
- EVEREST ELITE 700
- EVEREST ELITE 750NC
- Free
- Free X
- ~~GRIP 100/200~~
- ~~J22~~
- ~~J22I~~
- ~~J33~~
- ~~J33I~~
- ~~J46BT~~
- ~~J55~~
- ~~J55I~~
- ~~J56BT~~
- ~~J88~~
- ~~J88I~~

- JR300
- JR300BT
- ~~Reflect Aware~~
- Reflect Fit
- Reflect Contour
- Reflect Contour 2
- ~~REFLECT MINI~~
- REFLECT MINI 2
- REFLECT MINI BT
- Reflect Response
- ~~SYNCHROS E10~~
- ~~SYNCHROS E30~~
- SYNCHROS E40BT
- SYNCHROS E50BT
- ~~SYNCHROS REFLECT~~
- ~~SYNCHROS REFLECT BT~~
- ~~SYNCHROS S100~~
- ~~SYNCHROS S100a~~
- ~~SYNCHROS S100i~~
- ~~SYNCHROS S200~~
- ~~SYNCHROS S200a~~
- ~~SYNCHROS S200i~~
- ~~SYNCHROS S300i~~
- ~~SYNCHROS S400BT~~
- ~~SYNCHROS500~~
- ~~SYNCHROS700~~
- TUNE 110BT
- TUNE 120TWS
- TUNE 205BT
- TUNE 210
- TUNE 290
- TUNE 500BT
- T450
- T450BT

- UA Headphones Wireless - Engineered by JBL
- Under Armour Sport Wireless
- UA Sport Wireless FLEX
- UA Sport Wireless HEART RATE
- UA Sport Wireless PIVOT
- US Sport Wireless REACT
- UA Sport Wireless Train - Engineered by JBL
- Under Armour True Wireless Flash - Engineered by JBL

ホームシアター/ホームオーディオ

- Bar 2.1
- Bar 3.1
- Bar Studio
- Boost TV
- Cinema Base
- Cinema SB250
- Cinema SB350
- Cinema SB450
- ~~MX150~~
- ~~SAS100~~
- SAS101

Car ポータブル Bluetooth スピーカー

- Smartbase Wired
- Smartbase Wireless
- Trip
- Trip TRD

Car スピーカー/ウーファー

- 560GTI

- 660GTI
- 670GTI
- BassPro Hub
- BassPro Micro
- BassPro SL
- ~~C508GTi~~
- ~~C508GTiMK2~~
- ~~C508W~~
- ~~C608GTi~~
- ~~C608W~~
- CLUB 5000C
- CLUB 6500C
- CLUB 3020
- CLUB 4020
- CLUB 5020
- CLUB 6520
- CLUB 6420
- CLUB 9630
- CLUB 750T
- Club WS1000
- Club WS1200
- ~~GTO1014~~
- GTO1214
- ~~GTO429~~
- ~~GTO509C~~
- GTO529
- GTO609C
- GTO629
- ~~GTO804~~
- GTO939
- GX302
- GX402
- GX502
- GX600C

- GX602
- GX642
- GX963
- MS-10SD2
- MS-10SD2-SLIM
- MS-12SD2
- MS-52C
- MS-62C
- MS-BASSPROSQ
- P26F
- P560C
- P6563C
- P660E
- P662
- STADIUM GTO600C
- STADIUM GTO620
- STADIUM GTO930
- STADIUM GTO20M
- STADIUM GTO750T
- T696L
- W10GTI-MKII
- W12GTI-MKII
- W15GTI-MKII
- WS1000
- WS1200

Car パワーアンプ、その他

- CLUB 4505
- CLUB 5501
- CLUB 704
- GTO-1001EZ
- GTO1201.1MK2

- ~~GTO301.1MK2~~
- GTO-3EZ
- GTO-5EZ
- ~~GTO601.1MK2~~
- ~~GTO75.2MK2~~
- ~~GTO75.4MK2~~
- GTO-751EZ
- ~~GTO755.6MK2~~
- GTO-804EZ
- GTO-RBC
- GTR102
- GTR1001
- GTR104
- GTR601
- GTR7535
- GX-A3001
- GX-A602
- GX-A604
- ~~MS-2~~
- ~~MS-8~~
- ~~MS-A1004~~
- MS-A5001
- MS-WBC
- ~~PX300.4~~
- ~~PX600.2~~
- RBC
- STAGE A9004