

Mobile Phones	Tablets	Laptops	Gaming Devices
<p>Apple</p> <p>iPhone 15 Pro Max, iPhone 15</p> <p>Samsung</p> <p>Galaxy Note8(**), Galaxy Note 9, Galaxy Note10, Galaxy Note10+, Galaxy Note20, Galaxy Note20 Ultra, Galaxy A04S(**), Galaxy A9 Pro, Galaxy A13(**), Galaxy A23, Galaxy A33, Galaxy A42, Galaxy A52, Galaxy A53, Galaxy A54, Galaxy A60, Galaxy A71, Galaxy A72, Galaxy A73, Galaxy A90, Galaxy S8(**), Galaxy S8+(**), Galaxy S9(**), Galaxy S9+(**), Galaxy S10, Galaxy S10e(*), Galaxy S10+, Galaxy S20, Galaxy S21, Galaxy S21 Ultra, Galaxy S22, Galaxy S22 Ultra, Galaxy S23, Galaxy S23+, Galaxy S23 Ultra, Galaxy Z Fold4, Galaxy Z Fold2, Galaxy Z Flip3, Galaxy Z Flip</p> <p>Huawei</p> <p>Huawei Mate 30(*), Huawei Mate 40 Pro(*), Huawei Mate 50 Pro(*), Huawei P30(*), Huawei P40(*), Huawei P smart(*), Huawei nova Y60(*), Huawei nova 10(*)</p> <p>VIVO</p> <p>VIVO V23, VIVO V21, VIVO X70, VIVO X70 Pro, VIVO X70 Pro+, VIVO X80 Pro, VIVO X90 Pro+, VIVO iQOO 10 Pro, VIVO iQOO Z5, VIVO iQOO Z6, VIVO S9E, VIVO S10, VIVO Y21, VIVO Y33s, VIVO Y53s, VIVO Y50, VIVO X60, VIVO X Fold, VIVO X Fold+, VIVO X Note</p> <p>OPPO</p> <p>OPPO Reno8 T, OPPO Reno5 F, OPPO Reno 6, OPPO Reno 7 Pro, OPPO Reno 8, OPPO Reno 5 Pro, OPPO Reno Ace, OPPO F21 Pro(*), OPPO Find X3, OPPO Find X3 Pro, OPPO Find X5, OPPO Find X5 Pro, OPPO Find N, OPPO A97, OPPO A77, OPPO A57, OPPO A16</p> <p>One Plus</p> <p>OPPO Oneplus 11, OPPO Oneplus Ace 2, OnePlus 7 Pro, Oneplus 9, Oneplus 9R</p> <p>Google</p> <p>Google Pixel 7, Google Pixel 6Pro, Google Pixel 6, Google Pixel 5, Google Pixel 4, Google Pixel 4XL, Google Pixel 3XL, Google Pixel 3</p> <p>NOKIA</p> <p>Nokia G10, Nokia G20, Nokia 5.3, Nokia 5.4, Nokia 8.3 5G, Nokia X100</p> <p>Xiaomi</p> <p>Xiaomi POCO X4 Pro(*), Xiaomi POCO X4 GT(*), Xiaomi POCO M5(*), Xiaomi MIX4(*), Xiaomi 13(*), Xiaomi 13 Pro(*), Xiaomi Redmi 9T(*), Xiaomi Mi 11 Lite(*), Xiaomi Mi 9(*), Xiaomi Mi 10(*), Xiaomi Mi 10S(*), Xiaomi Mi 10T 5G(*), XiaoMi Mi 11 Ultra(*), Xiaomi Mi Max 3(*), XiaoMi 11 Pro(*), XiaoMi 9 Pro(*) (**), XiaoMi 12 Pro(*), Xiaomi Redmi K50 Pro(*), Xiaomi Redmi 12T Pro(*), Xiaomi Redmi Note 11, Xiaomi Redmi Note 11 Pro, Xiaomi Redmi Note 11S(*), Xiaomi Redmi 9(*), Xiaomi Redmi 10(*)</p> <p>Realme</p> <p>Realme GT, Realme Q3, Realme Q3 Pro, Realme X7, Realme V15, Realme 10 Pro, Realme X50 Pro</p> <p>Motorola</p> <p>Motorola Moto G Stylus 2021, Motorola Edge(2022), Motorola Moto G8</p> <p>LG</p> <p>LG G6 VS988, LG G8 ThinQ</p> <p>Gionee</p> <p>Gionee K10, Gionee GT2</p> <p>Sony</p> <p>Sony Xperia1, Sony Xperia XZ3</p> <p>Gaming Mobile Phones</p> <p>Xiaomi Black Shark2, Asus ROG Phone2, Nubia Red Magic3</p> <p>Umidigi</p> <p>Umidigi A9 Pro</p> <p>Nothing</p> <p>Nothing A063</p>	<p>Apple</p> <p>Apple iPad Air4, Apple iPad 10, Apple iPad Pro, Apple iPad mini6</p> <p>Samsung</p> <p>Galaxy Tab S5e(**), Galaxy Tab S6(**), Galaxy Tab S8, Galaxy Tab A8(**), Galaxy Tab S7</p> <p>Xiaomi</p> <p>Xiaomi Pad5, Xiaomi Pad6</p> <p>Huawei</p> <p>Huawei Matepad 11, Huawei Matepad Pro, Huawei Matepad T10</p> <p>OPPO</p> <p>OPPO Pad</p>	<p>Apple</p> <p>13Inch MacBook Pro (2022) M2, 24Inch iMac (2021) M1, 13Inch Macbook Pro (2020) M1, 21.5Inch iMac (2019), 13Inch Macbook air, 14Inch Macbook Pro (2021) M1, 13Inch MacBook Pro (2020) i5</p> <p>ASUS</p> <p>ASUS FL8000U, ASUS Mars15, ASUS RTX3050</p> <p>Lenovo</p> <p>Lenovo ThinkPad E490, Lenovo ThinkPad T480, Lenovo ThinkPad T14, Lenovo ThinkPad T570, Lenovo ThinkCentre E490, Lenovo Legion Y7000P, Lenovo Legion 7000K, Lenovo Legion Y9000K, Lenovo L480</p> <p>HP</p> <p>HP Zhan 66 Pro G1, OMEN 8, HP OMEN 5plus</p> <p>Samsung</p> <p>Galaxy Chromebook Enterprise Edition, Galaxy Chromebook V2, Galaxy Chromebook 4+,Galaxy Book S W767</p> <p>HUAWEI</p> <p>HUAWEI MateBook X Pro Signature Edition, HUAWEI Mate Book D14, HUAWEI MateBook 16S</p> <p>Xiaomi</p> <p>Xiaomi Book Pro 2022, Xiaomi Book Air 13</p> <p>Microsoft</p> <p>Microsoft Surface Book</p> <p>Alienware</p> <p>Aurora R8</p> <p>Dell</p> <p>XPS13 9360</p>	<p>Nintendo</p> <p>Nintendo Switch, Nintendo Switch Lite</p>

Note: The functionality of the USB-C may vary depending on the device
 *When used with this device, press and hold the central button on the headphones remote to end the call
 **Voice calls via USB-C are not supported with this device